


LifeFitness

Arctic Silver 95Re Recumbent Bike



Customer Support Services
PARTS MANUAL

ARCTIC SILVER 95Re
REFERENCES

95Re-0XXX-02
S/N CCT100000 and UP

OPERATION MANUAL	M051-00K39-A042
POWER SUPPLY: 12V; 4.5A Without Line Cord	118E-00001-0161
LINE CORD: DOM. 10A 125V	0017-00003-0704
LINE CORD: CON 10A 250V	0017-00003-0691
LINE CORD: 10A; UK	0017-00003-0889
LINE CORD: AUSTRALIA	0017-00003-0918
HARDWARE BAG	GK39-00002-0009
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
SERVICE MANUAL	M051-00K39-B012


ARCTIC SILVER 95Re
CONTENTS

95Re-0XXX-02
S/N CCT100000 and UP

	Page
CONSOLE ASSEMBLY	4
CONSOLE SUPPORT ASSEMBLY	5
SHROUDS, END CAP, CRANKARMS AND PEDALS	6
BELTS	7
RESISTOR ASSEMBLY	8
POWER CONTROL BOARD	9
ALTERNATOR W/PULLEY	10
CRANKSHAFT AND BEARING ASSEMBLY	11
INTERMEDIATE SHAFT AND BEARING ASSEMBLY	12
IDLER BRACKET ASSEMBLY	13
SEAT ASSEMBLY	14
SEAT BOTTOM ASSEMBLY	15
SEAT FRAME ASSEMBLY	16
SEAT PADS AND ACCESSORY TRAY	17
EXTRUSION ASSEMBLY	18
SEAT LOCKING ASSEMBLY	19
WHEEL AND LEVELER	20
CABLES	21

ARCTIC SILVER 95Re
Console Assembly


95Re-0XXX-02
S/N CCT100000 and UP



CONSOLE ASSEMBLY	
GK63-00002-0045	KIT: SERVICE CONSOLE NTSC ENG
GK63-00002-0046	KIT: SERVICE CONSOLE NTSC SPN
GK63-00002-0047	KIT: SERVICE CONSOLE NTSC JAP
GK63-00002-0048	KIT: SERVICE CONSOLE NTSC FRN
GK63-00002-0049	KIT: SERVICE CONSOLE PAL ENG
GK63-00002-0050	KIT: SERVICE CONSOLE PAL GER
GK63-00002-0051	KIT: SERVICE CONSOLE PAL SPN
GK63-00002-0052	KIT: SERVICE CONSOLE PAL FRN
GK63-00002-0053	KIT: SERVICE CONSOLE PAL ITL

ARCTIC SILVER 95Re
Console Support Assembly

95Re-0XXX-02
S/N CCT100000 and UP





ARCTIC SILVER 95Re


Shrouds, End cap and Pedals

95Re-0XXX-02

S/N CCT100000 and UP








ARCTIC SILVER 95Re
Power Control Board

95Re-0XXX-02
S/N CCT100000 and UP

Assembly Number - AK39-00092-0000



ARCTIC SILVER 95Re
Alternator w/pulley Assembly

95Re-0XXX-02
S/N CCT100000 and UP

Assembly Number – AK63-00093-0000


Alternator Pulley
0K61-02500-0001

Alternator
0017-00009-0841

Locking Nut
0017-00103-0117

Washer
0017-00104-0044


Bolt
0017-00101-0956



ARCTIC SILVER 95Re
Crank Shaft and Bearing Assembly

95Re-0XXX-02
S/N CCT100000 and UP

Kit Number – GK63-00002-0006




ARCTIC SILVER 95Re

Intermediate Shaft and Bearing Assy.


95Re-0XXX-02

S/N CCT100000 and UP

Kit Number – GK63-00002-0007




Idler Bracket Assembly – AK63-00021-0000




ARCTIC SILVER 95Re
Seat Assembly

95Re-0XXX-02
S/N CCT100000 and UP



ARCTIC SILVER 95Re
Seat Assembly - Bottom

95Re-0XXX-02
S/N CCT100000 and UP




ARCTIC SILVER 95Re
Seat Frame Assembly

95Re-0XXX-02
S/N CCT100000 and UP

ARCTIC SILVER 95Re
Seat Pads and Accessory Tray

95Re-0XXX-02
S/N CCT100000 and UP





ARCTIC SILVER 95Re

Extrusion Assembly – AK39-00027-0005

95Re-0XXX-02


S/N CCT100000 and UP





ARCTIC SILVER 95Re
Wheel and Leveler

95Re-0XXX-02
S/N CCT100000 and UP



ARCTIC SILVER 95Re

Cables

95Re-0XXX-02
S/N CCT100000 and UP

